

Instructions for Lithurin® Hard, indoors and outdoors

1. Apply Lithurin® HARD with a low-pressure sprayer or an LC applicator. Allow the material to react for about 15 min. Then scour the surface with LC Rider Pad 320 on a single trowel or ride-on trowel. At high temperatures; prewater the surface.
2. Lithurin® HARD must remain wet on the surface for at least 15 minutes before it is allowed to dry.
3. Important! Clean the surface with a combi scouring machine/wet vacuum cleaner before Lithurin® HARD dries.
4. With an extremely dry surface, prewater the surface in two steps; once the day before and once before application.
5. If the surface has already dried, repeat from step 1 as soon as possible
6. No residues of Lithurin® HARD should remain on the surface when the application is completed.
7. Under certain conditions, e.g. low temperatures, strong wind etc., the absorption time is longer and at higher temperatures the absorption time is shorter.

Consumption

- Machine trowelled surface: approx. 0.15 litres/m².
- Non-machine trowelled surface: approx. 0.2-0.4 litres/m².



ab lindec® endeavours to provide correct information about technical properties and handling of its products. However, while ab lindec® has no control over the way in which the products are mixed and laid, or the conditions under which they set, ab lindec® can in no way be held responsible. ab lindec® is only responsible for the quality of the products at the time of delivery.